



## GM 6.6L LLY Duramax Injector Installation Tips

### Read Before Installing This Injector

Perform a fuel system inspection prior to installation of replacement injectors. If rust, contamination, or metal particles are found the fuel system must be cleaned including the tank, filter housing, supply lines, and the high-pressure system. **Failure to completely clean the complete fuel system can result in immediate or repeated short-term injector failures.**

#### INSTALLATION TIPS

1. Use caution when working on the fuel system to prevent injury. The high-pressure side of the fuel system is pressurized up to 23,200 PSI and the injector wiring high voltage is 50 volts. Make sure the engine is off, the high-pressure has bled down, and the engine has cooled off prior to working on the fuel system.
2. The Engine Control Module (ECM) should be updated to the latest calibration as part of the diagnostic and repair process.
3. Before performing an injector balance test check that the actual rail pressure and the desired rail pressure match by performing a fuel pressure regulator graphing test. Unstable rail pressure will cause inaccurate injector balance rate results.
4. DTech fuel injectors have tolerances measured in microns. It is important to work in a clean manner to prevent contamination of the fuel system to prevent premature failures. Clean the engine area around the fuel system prior to removing any fuel system components. Before assembly inspect each component for dirt, grease, or other contaminants and clean as necessary.
5. The high-pressure injection lines from the rail to the injectors must be cleaned per GM bulletin 03-06-04-036B or replaced with new lines to prevent debris from entering the DTech injector fuel inlet.
6. Install a new fuel filter and do not fill it with fuel prior to installation.
7. Make sure that the injector bore in the cylinder head is clean and that the old injector body o-ring and nozzle-sealing washer have been removed.
8. Lubricate the injector body o-ring with clean engine oil and install the injector into the cylinder head.
9. Use shop air to blow any debris and fluids from the hold down bolt hole in the cylinder head.
10. Install the hold-down bracket pin and hold down bracket.
11. Install the hold-down bracket bolt and torque it to 22 ft-lb (30 Nm).
12. Connect the injector electrical connectors to the injector stator connection. Take care to connect each electrical connector to the proper cylinder location.
13. Install the injector return connectors and hose.
14. Install the injection lines and torque the injection line nuts to 30 ft-lb (41 Nm).

*(Continued on reverse side.)*

## Read Before Installing This Injector

*(Continued from front side.)*

Additional resources can be found at [www.dipacodtech.com/DTech-Product-Information-Bulletins](http://www.dipacodtech.com/DTech-Product-Information-Bulletins).

**Notice:** Injectors submitted for warranty that are damaged by contamination or with combustion blow-by are not covered under the DTech warranty.

DTech injectors are covered by a two year, unlimited mileage warranty. Complete warranty information can be found at [www.dipacodtech.com/warranty](http://www.dipacodtech.com/warranty).